



## InData Systems DPM190X DPM Plug-in Setup



PLGDNC<..>

First time only –  
set config. file name



PLGDCE1

**DPM Enable**



PLGDCE0

**DPM Disable**

### All Standard Decoding



ALLENA0

**Disable**



ALLENA1

**Enable**

### Data Matrix Decoding Disable if only linear required



IDMENA0

**Disable**



IDMENA1

**Enable**

**Save:**



\_RESET

**SCANNER**



\*\_RESET

**Cordless BASE**

[www.uvreaders.com](http://www.uvreaders.com)

Industrial Data Entry Automation Systems Incorporated  
27 Fennell Street Skaneateles, NY 13152  
Phone: (315) 685 8311 Fax: (315) 685-8312

---

**For testing and diagnostics:**



**Enable – debug mode - Disable**



**Display directory of Plug-ins**



**Display information of Plug-ins**

---

**Configure Common Interfaces:**

**Terminal ID = 124**



**USB- Keyboard**

**Terminal ID = 130**




**USB Com Port Emulation**

---

**Check DPM Decoder. If you can read Data Matrix symbols below, installation was successful.**



Test1 Data



Matrix xxx

---

Industrial Data Entry Automation Systems Incorporated

27 Fennell Street, Skaneateles, NY 13152

**Phone:** (315) 685-8311 **Fax:** (315) 685-8312